

Floor grille

11034416

F7 filter EasyVEC® 5000/6500/8000

Product description

Filters are used to clean the air blown into the building. They are available as accessories and should be installed inside the filter box.

Fields of application

Non-residential buildings

Installation

- for installation inside the filter box.

Main characteristics

- 4 types of filter:
 - ISO coarse 60%,
 - ISO ePM10 50%,
 - ISO ePM1 50-75%
 - ISO ePM1 85%.