

Floor grille**11034413****M5 filter EasyVEC® 5000/6500/8000****Product description**

Filters are used to clean the air blown into the building. They are available as accessories and should be installed inside the filter box.

Fields of application

Non-residential buildings

Installation

- for installation inside the filter box.

Main characteristics

- 4 types of filter:
 - ISO coarse 60%,
 - ISO ePM10 50%,
 - ISO ePM1 50-75%
 - ISO ePM1 85%.